


WOULD YOU LIKE TO **ADD MORE USERS**
OR **ADDITIONAL DEVICES** ?

subject to your housing manager subscribing to the video option

via « **My Intercom intratone** » app

Click on
« **My profile** »
then
« **Add a device** »



FIND THE CONFIGURATION
« **My Intercom intratone** » app



DISCOVER
STEP-BY-STEP HOW
TO INSTALL THE APP



DISCOVER
THE APP
IN VIDEO

intratone
access a better life




10-31-1980 / Certifié PEFC / This product comes from sustainably managed forests and controlled sources / pefc-france.org

Photo credits PEXELS and FREEPIK | Non-contractual photos | Studio Rose Citron for COGELEC ZEUK-FLY24-01

intratone
access a better life




**FIND OUT
HOW TO USE
YOUR NEW INTERCOM!**



YOUR ACCESS

OPEN THE DOOR

Hold your fob in front of the reader.



YOUR VISITORS' ACCESS



Your visitors
select your name
using the arrows



Then press

If you have a
push-button intercom,



as they have to do is press
the button corresponding
to your name.

You receive either
an **AUDIO CALL** or a **VIDEO CALL**



TIP:

Remember to save the intercom phone number in your phonebook after
the 1st call, so that you can easily identify calls from your intercom. This number
starts with +33 6 or +33 7 and is between 10 and 14 digits long.



AUDIO CALL FROM A LANDLINE OR CELL PHONE



When your intercom calls you on your landline or mobile phone, **PICK UP THE RECEIVER AND FOLLOW THE INSTRUCTIONS BELOW :**

Open your door by pressing *
*unless your housing manager has modified the key

Press the key 0
to talk to your visitor

Press the key 0
if you do not wish to open the door

IF THERE IS NO REPLY:
Your answering machine will not be triggered and the call will be transferred to the 2nd registered number after the 4th ring. In both cases, the answering machine is not triggered.



VIDEO CALL FROM A CELL PHONE

(subject to your housing manager subscribing to the video option)

To receive video calls, download the
« My Intercom intratOne » free app



2

3


PICK UP

to accept the call from
your smartphone

TALK

to your visitor.

OPEN the door
OR HANG UP.



Sound setting

Mic setting

Brightness setting

**Activate/deactivate
your microphone**

Open the door

**Activate/deactivate
your loudspeaker**

Hang up



IF YOU DON'T ANSWER THE VIDEO CALL, the intercom will call you on audio on the same number. If you don't answer this 2nd call, it will call you on video and then on audio on the 2nd number registered with your housing manager. In both cases, the answering machine is not triggered.

GOOD TO KNOW:

Remember to activate your WIFI in case of insufficient network coverage (min 3G).



Discover how the app works in video: